




SECTION 16: STALL WARNING



W-1208-L
NOSE RIB

W-1205-L
TERMINAL
BRACKET

WH-B216
TERMINAL
GROUND
WIRE
(WHT)

W-1206-L
SPAR ASSEMBLY

LEFT
STUB SPAR
ASSEMBLY

WH-B217
GROUND
WIRE
(WHT)

WH-B218
TERMINAL
WIRE
(WHT)

W-1208-R
NOSE RIB

VA-195A
MOUNT PLATE
VA-196
STALL
WARNING
VANE

VA-195B
KEEPER
PLATE

ES E22-50K
MICRO SWITCH

DATE OF COMPLETION: _____
PARTICIPANTS: _____